

# *Pineware*<sup>®</sup>



**INSTRUCTIONS AND WARRANTY**

**MODEL NO. PFH11**

**PINEWARE FAN HEATER**

Thank you for purchasing our Pineware Fan Heater. Please read the instructions carefully before using and keep safe for future reference. The following instructions will allow you to use this product to its maximum performance.

### **IMPORTANT SAFEGUARDS:**

When using any electrical appliance, basic safety precautions should always be followed including the following:

1. Please read the instructions carefully before using any appliance.
2. Always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
3. Incorrect operation and improper use can damage the appliance and cause injury to the user.
4. The appliance is intended for domestic use only. Commercial use invalidates the warranty and the supplier cannot be held responsible for injury or damage caused when using the appliance for any other purpose than that intended.
5. Avoid any contact with moving parts.
6. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
7. Children should be supervised to ensure that they do not play with the appliance.
8. Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, it must be replaced by the manufacturer or a qualified person in order to avoid an electrical hazard. Do not operate the appliance if the cord is damaged.
9. Do not use the appliance if it has been dropped or damaged in any way. In case of damage, take the unit in for examination and/or repair by an authorised service agent.
10. To reduce the risk of electric shock, do not immerse or expose the motor assembly, plug or the power cord to water or any other liquid.
11. Never immerse the full unit in water or any other liquid for cleaning purposes.
12. Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the appliance from the mains. Always unplug the unit when not in use, before cleaning or when adding or removing parts.

13. The use of accessory attachments that are not recommended or supplied by the manufacturer may result in injuries, fire or electric shock.
14. A short cord is provided to reduce the hazards resulting from becoming entangled in or tripping over a longer cord.
15. Do not let the cord hang over the edge of a table or counter. Ensure that the cord is not in a position where it can be pulled on inadvertently.
16. Do not allow the cord to touch hot surfaces and do not place on or near a hot gas or electric burner or in a heated oven.
17. Do not use the appliance on a gas or electric cooking top or over or near an open flame.
18. Place the power cable away from areas where people walk so that it cannot be stepped on or tripped over.
19. Use of an extension cord with this appliance is not recommended. However, if it is necessary to use an extension lead, ensure that the lead is suited to the power consumption of the appliance to avoid overheating of the extension cord, appliance or plug point. Do not place the extension cord in a position where it can be pulled on by children or animals or tripped over.
20. This appliance is not suitable for outdoor use. Do not use this appliance for anything other than its intended use.
21. DO NOT carry the appliance by the power cord.
22. Do not leave this appliance unattended during use. Always unplug the unit when not in use or before cleaning.
23. Always operate the appliance on a smooth, even, stable surface. Do not place the unit on a hot surface.
24. Ensure that the switch is in the "Off" position after each use.
25. The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use, or for repairs carried out by unauthorized personnel.
26. In case of technical problems, switch off the machine and do not attempt to repair it yourself. Return the appliance to an authorised service facility for examination, adjustment or repair. Always insist on the use of original spare parts. Failure to comply with the above-mentioned pre-cautions and instructions, could affect the safe operation of this machine.
27. Do not place the heater on windowsills or other places where it may be exposed to dripping or splashing water; do not place vases or similar objects filled with liquids near the heater.
28. Never touch the appliance with wet or damp hands or feet.

29. Do not use the appliance in bathrooms or in areas with high damp and humidity or close to water.
30. Never expose the appliance to atmospheric conditions such as rain, sun, wind etc.
31. To avoid the risk of overheating, ensure the cable is completely unwound when in use.
32. Only plug in and switch on the appliance when it is in use, when not in use always switch the appliance off and unplug it.
33. Ensure the air inlet and outlet is not obstructed.
34. Ensure the appliance is kept a minimum distance of 50 cm from walls or any objects and ensure the airflow is not directed to the wall or the objects.
35. Do not leave the appliance unattended when it is on.
36. Ensure that the cord is not in front of warm air outlet grille when in use.
37. Use the appliance in horizontal position.
38. Ensure the grills are kept clean.
39. Never install and use the appliance immediately below a fixed outlet.
40. Do not use the appliance near liquids or flammable gases or materials.
41. Do not cover the appliance.
42. Ensure the appliance is kept clean.
43. The appliance must not be positioned directly underneath a fixed power point.
44. Do not use the appliance in rooms that are smaller than 4m<sup>2</sup>.
45. Do not use this heater with a programmer; timer, separate control system or any other device that switches the heater on automatically.

**IMPORTANT: ENSURE THE APPLIANCE IS USED IN THE UPRIGHT POSITION AT ALL TIMES.**

**CAUTION: DO NOT ALLOW THE HEATER TO TIP OVER**

## PARTS DIAGRAM:



- A. Carry handle
- B. Grill
- C. On\ Off Indicator light
- D. Variable temperature control
- E. Heat & speed setting control

## OPERATING INSTRUCTIONS

Plug in the appliance.

Select the speed & heat by the turning the heat and speed setting control clockwise.

~ = Warm air (1200W)

≈ = Hot air (2000W)

☪ = Cool setting

- The temperature can also be adjusted by adjusting the variable temperature control. Turning it clockwise will increase the temperature and turning it anti-clockwise will decrease the temperature.
- When the desired temperature is attained the heater will switch off automatically and switch back on once the temperature drops again.

- If you turn the thermostat knob clockwise and you reach the highest position the fan heater will continuously work.
- NOTE: This appliance is provided with a safety device that switches off the appliance in case of overheating.
- To deactivate the safety device, switch off the appliance and unplug it until it cools down (about 10 minutes). Plug it again and switch it on.

#### **CLEANING AND MAINTAINANCE:**

- Ensure the unit is switched off and unplugged.
- Ensure the unit has cooled down.
- Clean the air inlet/ outlet grills frequently. This can be done with a damp cloth or a duster.
- Never use abrasive powders or solvents.
- Do not stick any objects into the grills or vents to try and clean them.

#### **STORING THE APPLIANCE:**

1. Unplug the unit from the wall outlet and clean all the parts as instructed above. Ensure that all parts are dry before storing.
2. Store the appliance in its box or in a clean, dry place.
3. Never store the appliance while it is still wet or dirty.
4. Store the appliance in a cool dry place.

#### **SERVICING THE APPLIANCE:**

There are no user serviceable parts in this appliance. If the unit is not operating correctly, please check the following:

- You have followed the instructions correctly
- That the unit has been wired correctly and that the wall socket is switched on.
- That the mains power supply is ON.

If the appliance still does not work after checking the above:

- Consult the retailer for possible repair or replacement. If the retailer fails to resolve the problem and you need to return the appliance, make sure that:

- The unit is packed carefully into its original packaging.
- Proof of purchase is attached.
- A reason is provided for why it is being returned.


If the supply cord is damaged, it must be replaced by the manufacturer or an authorised service agent in order to avoid any hazard. If service becomes necessary within the warranty period, the appliance should be returned to an approved Home of Living Brands (Pty) Ltd service centre. Servicing outside the warranty period is still available, but will, however, be chargeable.

### CHANGING THE PLUG:


Should the need arise to change the fitted plug, follow the instructions below.

**This unit is designed to operate on the stated current only. Connecting to other power sources may damage the appliance.**

**WARNING:** If your appliance has three wires (Green/Yellow, Blue, Brown) then it **MUST** be earthed. Connect a three pin plug as shown below



If your appliance has only two wires (Blue, Brown) then it does not need to be earthed. Connect a three pin plug as shown below



**PLEASE AFFIX YOUR PROOF OF PURCHASE/RECEIPT HERE  
IN THE EVENT OF A CLAIM UNDER WARRANTY THIS RECEIPT MUST BE PRODUCED.**

*WARRANTY*

1. Home of Living Brands (Pty) Limited ("Home of Living Brands") warrants to the original purchaser of this product ("the customer") that this product will be free of defects in quality and workmanship which under normal personal, family or household use and purpose may manifest within a period of 1 (one) year from the date of purchase ("warranty period").
2. Where the customer has purchased a product and it breaks, is defective or does not work properly for the intended purpose, the customer must notify the supplier from whom the customer bought the product ("the supplier") thereof within the warranty period. Any claim in terms of this warranty must be supported by a proof of purchase. If proof of purchase is not available, then repair, and/or service charges may be payable by the customer to the supplier.
3. The faulty product must be taken to the supplier's service centre to exercise the warranty.
4. The supplier will refund, repair or exchange the product in terms of this warranty subject to legislative requirements. This warranty shall be valid only where (a) the customer is not the cause of the product breaking, and (b) the product has been used for the intended purpose stipulated in the product manual. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, tamper, abuse or any unauthorised modification or repair of the product.
5. This warranty will extend only to the product provided at the date of the purchase and not to any expendables attached or installed by the customer. In this regard any accessories supplied with the product by the supplier, may be excluded in this warranty or extended warranty (see Exclusions to Warranty document).
6. If the customer requests that the supplier repairs the product and the product breaks or fails to work properly within 3 (three) months of the repair and not as a result of misuse, tampering or modification by or on behalf of the customer, then the supplier may replace the product or pay a refund to the customer, subject to the supplier's discretion.
7. The customer may be responsible for certain costs where products returned are not in the original packaging, or if the packaging is damaged. This will be deducted from any refund paid to the customer.

**HOME OF LIVING BRANDS (PTY) LTD (JOHANNESBURG)**

NATIONAL CONTACT  
JOHANNESBURG  
CAPE TOWN  
DURBAN

TEL NO. (087) 245-0029  
TEL NO. (011) 490-9600  
TEL NO. (021) 552-5161  
TEL NO. (031) 303-1163

[www.homeoflivingbrands.com](http://www.homeoflivingbrands.com)  
[www.pineware.co.za](http://www.pineware.co.za)